AutoMARK

Closing Handbook

CLOSING HANDBOOK

Step 1



AFTER VOTING HAS ENDED:

Using the gold key, turn the key to the left (OFF) position.

The light will turn red and the monitor will go black

Step 2



Fold the Ballot Feed Tray up.

If any accessories, such as headphones are attached, please remove.

Step 3



Lift the lid and gently put the monitor down in the machine

Step 4




Lower the lid over the monitor.



Slide the plastic clips towards the center to secure

Step 5



Remove the gold key.
The red light will go off once the unit is unplugged.

Place Key in a safe place

Step 6





Gather all the Auto**MARK** accessories and place in the AutoMARK case

Unplug the cord from the outlet and the AutoMARK.





Return AutoMARK to its case and close clasps

Thank you for a job well done!

